CA DEPARTMENT OF COMMUNITY SERVICES & DEVELOPMENT (CSD)

© RHA • 1/15/03

COMBUSTION APPLIANCE SAFETY INSPECTION FORM (CASIF) Page 1 of 6

© 1111/10 1/10/00	•	20011011711121111	10_ 0/			(6/1611)	rage roro
Client:			D;	ate:		☐ SERVIC	E REQUIRED
Address:			Ci	ity:		_	
Agency:			Home Typ	e: □-SF	-, □-MF, □-M/H	Date:	ECTED
(A) IMMEDIATE	: SERV	/ICE REQUIRED (Z-	-1)				
Appliance	e and c	description of proble	:m		Repairs made	· By whom ·	Date
(B) OTHER REC	QUIRE	D REPAIRS (Z-2)					
		description of proble	;m		Repairs made	· By whom ·	Date
(C) FINAL TEST	r RESI	JLTS (L-5) ⁻	· Step F	-3c: <u>S</u>	econd Living Spa	ace Ambient C	O: ppm
APPLIANCE	Not App- licable	CO (ppm for each b			DRAFT	SPILLAGE	COMB. AIR
Main Heater*	NA				iwc/Pa P F	Y N NA	IN OUT OK
Other Heater*	NA			-	iwc/Pa P F	Y N NA	IN OUT OK
	NA				iwc/Pa P F		IN OUT OK
Water Heater	NA				iwc/Pa P F	Y N NA	IN OUT OK
Cook Top	NA	CO ppm: LR	_, RR	_, LF	, RF	, Others:	
Oven & Broiler	NA	CO ppm: Oven #1_					
Clothes Dryer	NA	CO ppm:	Inside	living sp	ace? Y N	Vented outdoo	ors? Y N
* For <i>Mobile Homes</i> , s	ee M/H W	VIS Appendix D regarding C	AZ test require	ment wher	n an open combustion ç	gas heater or wood s	stove is present.
(D) COMMENTS	3 AND	RECOMMENDED F	REPAIRS				
· /							
PRE-TEST: Tec	chnician	Signature:	<u></u>			Date:	
		Signature:					

(E) CLIENT INTERVIEW (All combustion appliances and exhaust devices off prior to Ambient CO tests.)

` '	· · · · · · · · · · · · · · · · · · ·
	How many people live in your home? # \cdot Do any large pets (dogs) live or sleep indoors? N Y \rightarrow # Which appliances burn gas? \Box -Furnace/Heater(s), \Box -W/H, \Box -Cooking, \Box -Dryer, \Box -Gas Log/Lighter, \Box -Gas F/P
	Type of gas: \Box -Natural Gas, \Box -Propane. \cdot Do any appliances burn Oil? N Y \rightarrow \Box -Furnace,
	Have you noticed any gas odors or leaks? N $\mathbf{Y} \rightarrow$
□ E-5	Have you had have any problems with any gas (oil) appliance? N $\mathbf{Y} \rightarrow \underline{\hspace{1cm}}$
□ E-6	Do you use: \square -Wood, \square -Pellets, \square -Coal? N $\mathbf{Y} \to \square$ -Stove, \square -Insert, \square -Fireplace,
□ E-7	Do you ever use a portable kerosene or gas heater to warm any part of the house? N $Y \rightarrow Unvented$? N $Y \rightarrow If$ used: How long ago was it used? \Box -Earlier today, \Box -Yesterday, \Box -More than a day ago.
□ E-8	[Gas Oven] When was you oven used last? For how long?
	\cdot Do you ever use your oven to take the chill off? N $\mathbf{Y} \rightarrow$
□ E-9	Do you have more than one furnace/heater? #: Location(s):
□ E-10	Where is your water heater located? Do you get enough hot water? Y N
□ E-11	[Attached Garage] Do you park cars in the garage? N $Y \rightarrow _$ # cars. Is a car warmed up in the garage? N Y
□ E-12	[FAU] Are any rooms noticeably colder (warmer) than others? N Y \rightarrow
□ E-13	[FAU] Please show me where all registers are located (and which rooms are colder/warmer). [Check airflow during step F-3.a.]
•	

Conditions for *Initial* <u>Living Space</u> **Ambient CO Test** (See Conventional WIS Appendix H): • All combustion appliances, air handler, and exhaust devices in living space <u>off</u>. • Exterior doors and windows <u>closed</u>. • Interior doors <u>open</u> (*except* appliance enclosure door, which is closed). • Fireplace damper <u>closed</u> if feasible (no fire or hot coals present).

(F) AMBIENT CO MEASUREMENTS (Keep exhaust devices off during Ambient CO tests.)

Record	CO Analyzer readings and calculations in "Pre-Wx Test" column.	Pre-Wx Test	References	
□ F-1	 (a) Set Conditions for <i>Initial</i> <u>Living Space</u> Ambient CO Test. (b) Zero CO analyzer <u>outdoors</u> ("outdoor" reading). (c) Draw an air sample <u>indoors</u> (see Z-6). (d) <u>Record the</u> <u>difference</u> between "outdoor" and <i>this</i> indoor CO reading. 	Test Conditions set? Y N Initial Living Space Ambient CO: ppm (with all appliances and fans off)	See Z-6 and WIS pages 1-5, H-1, and H-2.	
□ F-2	Check furnaces and heaters for gas leaks (see Z-3) prior to operating them. [If leaks, STOP! See Z-1.]	Gas leaks? Y N		
□ F-3	(a) Operate all furnaces and heaters for 5 minutes, with all other combustion appliances and exhaust devices still off, and all doors and windows unchanged. (b) Draw a second air sample from the same indoor location (step F-1c). (c) The difference between this reading and the "outdoor" reading is the "Second Living Space Ambient CO". [If it is 10 ppm CO or more, see Z-6 (3 & 4) and WIS p. 1-5.]	Furnaces/Heaters operating? Y N Second Living Space Ambient CO: ppm (with all furnaces and heaters on) [Also record at top of Section C.]	See Z-6, and WIS pages 1-5 and H-3.	
□ F-4	Immediately following step F-3 (with all furnaces/heaters operating, fans still off, doors/windows unchanged), check for Appliance Ambient CO (A or B) for each furnace/heater: A. [FAU] Check for CO in register nearest the furnace. B. [Wall, Floor, other non-ducted] Check for CO just above the heat exchanger. (See WIS 1-5 & H-3) If any CO above Second Living Space Ambient is detected, corrective action is required. (See Z-1 and WIS page 1-5)	(Show CO for each furnace/heater.) Appliance Ambient CO: ppm, ppm ppm, ppm Is Appliance Ambient CO higher than Second Living Space Ambient reading? Y N	(No change or a decrease is OK, but CO reading should not increase.) See Z-1 & Z-6 and WIS pages 1-5 and H-3.	

Conditions for Appliance Testing (X-4): • Exterior doors & windows <u>closed</u>. • Interior doors <u>closed</u> to appliance enclosures, and to rooms with a door separating a supply register from central return (even if room also contains a fan). • Interior doors <u>open</u> to hallways, to rooms without supply register, and to rooms with exhaust fan, clothes dryer, etc. • Fireplace damper closed. • Exhaust devices <u>on</u> (see X-4.2). • Reminder: Check all gas appliances, even if one fails or cannot be completely tested.

Circle answers in columns to the right: Y = Yes, N = No, NA = Not Applicable, U = Unverifiable When Post-Wx Test is performed, recheck all items with answers in "Post-Wx Test" column.	Pre-Wx Test	Post-Wx Test		
(G) GAS HOME HEATING SYSTEM ☐ Main Heater, ☐ Additional Heater · Location:	NA			
☐ G-1 Establish Appliance CAS Test conditions (different from Ambient Test conditions; see X-4 & WIS pages 1-6 & 1-7).	Conditions set for Appliance tests? Y N	Y N		
☐ G-2 Check for gas leaks (see Z-3). [If leaks, STOP! See Z-1.]	Leaks? (Step F-2) Y N	ΥN		

(G) GAS HOME HEATING SYSTEM (cont'd)	Pre-Wx Test	Post-Wx Test
☐ G-3 Circle type of heater (Forced Air Unit = FAU, Wall Furnace = WF, Floor Furnace = FF, Direct Vent = DV, Free Standing = FS.)	Type: FAU WF FF DV FS Other:	
☐ G-4 Does the heater (and air handler if an FAU) work properly? [If No, see Z-2.] FAU filter must be clean or removed (X-4.5).	Unit works properly? Y N Filter: □-Clean, □-Removed, □-NA	Filter: □-Clean, □-Removed, □-NA
☐ G-5 From where does furnace/heater draw combustion air?	Air from: □-Inside, □-Outside	
☐ G-6 Is furnace/heater "open" or "closed" combustion?	Combustion: □-Open, □-Closed	
☐ G-7 Is furnace/heater "natural" or "induced" draft?	Draft: □-Natural, □-Induced	
☐ G-8 Does furnace/heater share a common vent? [If YES, see X-3.] Shares with: ☐-Water Heater,	Common vent? Y N	
□ G-9 Record Btu/hr input ratings (see Z-8) of <i>open</i> combustion Furnace and Water Heater in this room or space* (<i>do not include Range, Oven, or Clothes Dryer</i>): +	Total: Btu/hr Input	(*Applies only to units that draw combustion air from the room or space.)
 (c) for vent size if vented indoors. (a) (# Thousand Btu/hr) , 4 = sq. in. NFVA required for each of 2 vents outdoors (one upper and one lower).→ 	(a) Existing vents NFVA sq. in.: Upper:, Lower:	
(b) (# Thousand Btu/hr) \mathbf{x} 50 = \mathbf{cu} . ft. , which is the <i>required</i> minimum room volume (if inadequate, use \mathbf{c} below). \rightarrow	(b) Room volume: cu. ft.	
(c) (# Thousand Btu/hr) $_{\ \ }$ 1 = sq. in. NFVA for upper & lower vents indoors (minimum 100 sq. in. NFVA each). \rightarrow	(c) Existing vents NFVA sq. in.: Upper:, Lower:	
Is there adequate combustion air? [If No, see Z-2.] $\;\; ightarrow\;\; ightarrow\;\; ightarrow$	Combustion air OK? Y N NA	Y N NA
☐ G-10 Is there a large amount of carbon or rust present in the ☐-heat exchanger, ☐-draft hood, ☐-flue or vent pipe? [If Yes, mark here and describe in (D).]	Large amount of: Carbon? Rust? V N	Y N Y N
☐ G-11 Does visual inspection of heat exchanger show any evidence of a crack, other defect? [If Yes, see Z-1.]	Heat exchanger defects? Y N U	ΥN
☐ G-12 [FAU] Are there return leaks that draw air from an open combustion appliance room/enclosure? [If YES, see Z-2.]	Return leaks? Y N NA	Y N NA
☐ G-13 Does visual inspection of Flue/Vent System (see Z-4) show evidence of <i>Immediate Service Required</i> (missing, double, or misaligned draft hood, because, leaks, disconnections,		[Check attic for disconnected pipes & air vent blockage.]
etc.)? [If Yes, see Z-1. For other service/repairs needed (e.g., missing vent cap), see Z-2.]	Flue/Vent defects? Y N	ΥN
☐ G-14 Are there any other missing/defective items (e.g., appliance door, combustion chamber door, roll-out shield)? (See Z-2.)	Any other defects? Y N NA	Y N NA
☐ G-15 Drill hole for draft test (see X-8). If not done, check reason: ☐-no feasible location, ☐-asbestos pipe, ☐-double-wall pipe, per restrictions on WIS page 1-9.	(Both Natural & Induced Draft) Drilling test hole? Y N NA	
☐ G-16 To conduct appliance tests, turn on exhaust devices (X-4.2) and commonly-vented appliances (per X-3). Turn on furnace/heater. Note when burner lights for 5-minute warm-up. Look for delayed ignition and roll-out (see Z-5).	Exhaust devices on? Y NA Delayed ignition? Y N U Roll-out ignition? Y N NA	Y NA Y N U Y N NA
☐ G-17 Observe burner flame pattern and color. Note presence of large yellow flame, soft lazy flame or other abnormalities. (See Z-5.1.)	Large yellow flame? Y N U Soft lazy flame? Y N U Other problems? Y N	Y N U Y N U Y N
☐ G-18 [FAU] When the blower comes on, is there a change in the flame pattern or color? [If Yes, see Z-5.1.]	Flame interference? Y N NA	Y N NA

(G) G	GAS HOME HEATING SYSTEM (cont'd)	Pre-Wx Test	Post-Wx Test
□ G- 19	Reinstall all access covers removed for inspection.	Covers reinstalled? Y NA	Y NA
□ G- 20	After at least 5 minutes of burner operation, check listed items with room door open (see X-7,8,9). [See Z-6 & Z-7 to analyze results; run longer and retest if first CO is high.] *If unable to use Draft Gauge, do "Smoke Test" (see Z-7), and write in "smoke" and circle "P" (Pass) or "F" (Fail). → ↗	(Door Open) CO:,,, ppm *Draft: iwc/Pa P F NA Spillage present? Y N NA Outdoor temperature:°F	,,,ppmiwc/Pa P F
□ G- 21	If applicable, <u>close</u> door to appliance enclosure or space and repeat tests. [See X-7 for procedures and Z-6 & Z-7 to analyze test results.]	(Door Closed) Y NA CO:,,, ppm *Draft: iwc/Pa P F NA Spillage present? Y N NA	,,,,,,,,,,,
□ G- 22	[FAU] If burner turns off and on before room temperature reaches wall thermostat setting, note "short cycling" here and in (D). If air in the nearest register exceeds 140 °F, advise client to not use furnace until corrected.	Short cycling? Y N NA If Yes, check temperature inside nearest register. Cycles off at:°F	Y N NA°F
□ G- 23	[Draft Test Hole Drilled] Seal test hole in single-wall pipe with "plug button" (or button plus tape), or in double-wall with lag bolt and high-temp caulk. (See X-8.3 & WIS page 1-9.)	Test hole sealed? Y NA	Y NA
□ G- 24	Thermostat set to normal? [FAU] Clean filter in place?	T'stat & Filter OK? Y N NA	Y N NA
□ G- 25	For each additional gas furnace/heater present, repeat steps G-1 thru G-24 using blank CASIF pages 2-4.	Testing other heater? Y NA	Y NA
	swers in columns to the right: Y = Yes, N = No, NA = Not Applicable, U = Unverifiable ost-Wx Test is performed, recheck all items with answers in "Post-Wx Test" column.	Pre-Wx Test	Post-Wx Test
(H) G	AS LOG/LIGHTER & GAS FIREPLACE UNIT	NA	
□ H-1	□-Gas Log, □-Gas-Fired Log Lighter, □-Gas Fireplace,: Check for gas leaks (see Z-3). [If leaks, STOP! See Z-1.]	Gas leaks? Y N	YN
□ H-2	For Gas Log, fireplace damper must function and should be permanently blocked open (see Z-4.3.c).[If not OK, see Z-2.]	Damper OK? Y N	Y N
□ H-3	[Gas Log used as Primary Heater] Check CO (see X-9). [Heat ceramic logs at least 10 minutes; run longer and retest if first CO is high.] Perform "Smoke Test" along fireplace opening (see Z-7). →	CO ppm NA Visual Draft Test: P F	ppm
□ H-4	[Gas Fireplace Unit used as Primary Heater] After at least 5 minutes of operation, check CO (see X-9). [Heat ceramic logs at least 10 minutes.] Perform "Smoke Test" (see Z-7).	CO ppm NA Visual Draft Test: P F	ppm
	swers in columns to the right: Y = Yes, N = No, NA = Not Applicable, U = Unverifiable ost-Wx Test is performed, recheck all items with answers in "Post-Wx Test" column.	Pre-Wx Test	Post-Wx Test
(I) G	AS WATER HEATER	NA	
□ I-1	Check for gas leaks (see Z-3). [If leaks, STOP! See Z-1.]	Gas leaks? Y N	ΥN
□ I-2	Is combustion air drawn from inside or outside living space? Combustion type? \Box -Open, \Box -Closed. Draft type? \to \to	Air from: □-Inside, □-Outside Draft: □-Natural, □-Induced	
□ I-3	Does water heater share a common vent? [If yes, see X-3] Shares with: □-Furnace,	Common vent? Y N	
□ I-4	Is there a large amount of carbon or rust present in the □-comb. chamber, □-center tube, □-draft hood, □-flue or vent pipe? [If Yes, mark here and describe in (D).]	Large amount of: • Carbon? • Rust? Y N	

(I) G/	AS WATER HEATER (cont'd)	Pre-Wx Test	Post-Wx Test
□ I-5	Is <i>Immediate Service Required</i> for the flue or vent (Z-4): missing, double or misaligned draft hood; blockage, leak, disconnection, etc.? [If Yes, see Z-1.] Are parts missing	(Post-inspection note when ceiling insulation was installed) → →	[Check attic for disconnected pipes & air vent blockage.]
	(e.g., no vent cap, no combustion chamber door), or is Other Service/Repair Required? [If Yes, see Z-2.]	Is service/repairs required? Y N	ΥN
(a) for	Record Btu/hr input ratings (see Z-8) of <i>open</i> combustion Furnace and Water Heater in this room or space* (do <u>not</u> include Range, Oven, or Clothes Dryer):	Total: Btu/hr Input	(*Applies only to units that draw combustion air from the room or space.)
(a) require	(# Thousand Btu/hr) , 4 = sq. in. NFVA ed for each of 2 vents <u>outdoors</u> (one upper and one lower).→ (# Thousand Btu/hr) x 50 = cu. ft. , which is	(a) Existing vents NFVA sq. in.: Upper**:, Lower:	**See Y-2 (D) for Mobile Homes.
	quired minimum room volume (if inadequate, use \mathbf{c} below). \rightarrow	(b) Room volume: cu. ft.	
	(# Thousand Btu/hr) ¸ 1 = sq. in. NFVA for & lower vents indoors (minimum 100 sq. in. NFVA each).→	(c) Existing vents NFVA sq. in.: Upper:, Lower:	
	Is there adequate combustion air? [If No, see Z-2.] \rightarrow \rightarrow	Combustion air OK? Y N NA	Y N NA
□ I-7	Drill hole for draft test (see X-8). If not done, check reason: □-no feasible location, □-asbestos pipe, □-double-wall pipe, per restrictions on WIS page 1-9.	(Both Natural & Induced Draft) Drilling test hole? Y N NA	
□ I-8	To conduct appliance tests, turn on exhaust devices (X-4.2) and commonly-vented appliances (per X-3). Mark thermostat, then turn it up. Note when burner lights for 5-minute warm-up. Look for delayed ignition and roll-out (see Z-5).	Exhaust devices on? Y NA Delayed ignition? Y N U Roll-out ignition? Y N NA	Y NA Y N Y N NA
□ I-9	Observe burner flame pattern and color. Note presence of large yellow flame, soft lazy flame, or other abnormalities. (See Z-5.1.)	Large yellow flame? Y N U Soft lazy flame? Y N U Other problems? Y N	Y N U Y N U Y N
□ I-10	Reinstall all access covers removed for inspection.	Covers reinstalled? Y NA	Y NA
	After at least 5 minutes of burner operation, check listed items with room door open (see X-7,8,9). [See Z-6 & Z-7 to analyze results; run longer and retest if first CO is high.] *If unable to use Draft Gauge, do "Smoke Test" (see Z-7), and write in "smoke" and circle "P" (Pass) or "F" (Fail). → ↗	(Door Open) CO: ppm *Draft: iwc/Pa P F NA Spillage present? Y N NA Outdoor temperature:°F	CO: ppm iwc/Pa P F Y N NA Temp:°F
□ I-12	If applicable, <u>close</u> door to appliance enclosure or space and repeat tests. [See X-7 for procedures and Z-6 & Z-7 to analyze test	(Door Closed) Y NA CO: ppm *Draft: iwc/Pa P F NA	NA CO: ppm iwc/Pa P F
	results.]	Spillage present? Y N NA	Y N NA
□ I-13	[Draft Test Hole Drilled] Seal test hole in single-wall pipe with "plug button" (or button plus tape), or in double-wall with lag bolt and high temp caulk. (See X-8.3 & WIS page 1-9.)	Test hole sealed? Y NA	Y NA
□ I-14	Return thermostat to original setting.	Thermostat reset? Y NA	Y NA

Circle answers in columns to the right: $Y = Yes$, $N = No$, $NA = Not$ Applicable, $U = Unverifiable$ When Post-Wx Test is performed, recheck all items with answers in "Post-Wx Test" column.	Pre-Wx Test	Post-Wx Test
(J) GAS COOK STOVE & OVEN/BROILER	NA	
☐ J-1 Check for gas leaks (see Z-3). [If leaks, STOP! See Z-1.]	Gas leaks? Y N	ΥN
☐ J-2 Is there a kitchen exhaust vent to the outdoors?	Exhausts outdoors? Y N	

(J) G	AS COOK STOVE & OVEN/BROILER (cont'd)	Pre-Wx Test	Post-Wx Test
□ J-3	[Exhausts Outdoors] Is there a fan in the exhaust vent? Does fan work OK? [Mobile Home: Kitchen must have an operable exhaust fan or metal duct. See CSD Mobile Home WIS, page 1-13.]	Fan present? Y N NA Fan works OK? Y N NA	Y N NA Y N NA
□ J-4	Cook Top: With exhaust fans on (X-4.2), light first burner on high for test. After minimum 15-second burn, check CO with probe held horizontally approx. 12" above the flame (see X-9.2.a). Test, turn off, light next burner & repeat. Burn Griddle on high for 5 minutes and test (see X-9.2.b). →	Exhaust fans on? Y NA LR, RR ppm CO ppm CO LF, RF ppm CO ppm CO Griddle: ppm CO	Y NA,
□ J-5	Operate each Oven & Broiler burner at least 5 min. Sample CO in exhaust stream. [See X-9.2.c for test locations; run 15-30 min. longer and retest if first CO reading is high.] [Single-Burner Oven] Operate on highest bake setting or "Broil". Record CO ppm on "Oven" line. [Two-Burner Oven (with broiler burner at top of oven)] (1) Run on highest bake setting; record CO on "Oven" line. (2) Turn control to "Broil", wait at least one minute, and check CO again. Record this reading on "Broiler" line. [Separate Broiler] Operate on "Broil" 5 to 30 minutes and check CO. Record CO ppm on "Broiler" line.	Oven #1: ppm CO Broiler #1: ppm CO Oven #2: ppm CO Broiler #2: ppm CO	ppm CO ppm CO ppm CO ppm CO

	swers in columns to the right: Y = Yes, N = No, NA = Not Applicable, U = Unverifiable ost-Wx Test is performed, recheck all items with answers in "Post-Wx Test" column.	Pre-Wx Test	Post-Wx Test
(K) G	AS CLOTHES DRYER	NA	
□ K-1	Check for gas leaks (see Z-3). [If leaks, STOP! See Z-1.]	Gas leaks? Y N	ΥN
□ K-2	Is combustion air drawn from inside or outside living space?	Air from: □-Inside, □-Outside	
□ K-3	Is the dryer properly exhausted to outdoors? \rightarrow \rightarrow [If not, corrective action is required (see Z-2).] Also check moisture exhaust tube for leaks, improper termination, obstructions, etc. Record Required Repairs in (B). \rightarrow	Exhausted outdoors? Y N Repairs required? Y N	Y N Y N
□ K-4	With exhaust devices on (see X-4.2), and lint filter clean, operate empty dryer for 2 minutes on high heat setting. With room door open (X-7), check CO in moisture exhaust termination or top-mount lint-screen cavity (see X-9.1.c). [Make sure burner is on while CO is being sampled.]	Exhaust devices on? Y NA Empty, filter clean? Y NA (Door Open) CO: ppm	Y NA Y NA ppm
□ K-5	If applicable, <u>close</u> door to the room where dryer is located and again check CO.	(Door Closed) NA CO: ppm	ppm

(L) WRAP-UP PROCEDURE		Pre-Wx Test			Post-Wx Test	
□ L-1	Turn off exhaust devices operated for tests.	Exhaust devices off?	Υ	NA	Υ	NA
□ L-2	Reset thermostats to normal. [FAU] Clean filter in place?	T'stats & Filter OK?	Υ		Y	
□ L-3	Make sure all appliance access panels are in place.	Panels in place?	Υ		Y	
□ L-4	[Draft Test Hole(s) Drilled] Seal test hole in single-wall pipe with "plug button" (or button plus tape), or in double-wall with lag bolt and high-temp caulk. (See X-8.3 and WIS page 1-9.)	Test hole(s) sealed?	Υ	NA	Υ	NA
□ L-5 Transfer Final test results to Section (C) on page 1. • When Post-Wx Tests are performed, transfer Post-Wx Test data. • When Post-Wx Tests are not per-formed, use Pre-Wx Test data. • When both Open and Closed Door tests are performed, transfer "worst case" readings.			Data tran to page 1 Y			